

## Single head grinder 415v

Weight(kg)	Height(mm)	Width(mm)	Length(m)	Hand arm vibration	Noise(db)
145	1200	300	1200	2.8m/s <sup>2</sup>	82



### EACH TIME BEFORE USING MACHINE

This machine should only ever be used by a trained and competent person.

Upon acceptance, please check the machine has in no way been damaged in transit and works, and each time prior to use. If you have any questions or doubts, please contact us, also in the event of breakdown or damage.

Please check that all safety mechanisms and switches are intact and working correctly.

Please make sure that the floor you're about to prep is clear of all foreign objects that could cause damage to the machine or operator. This must be completed every time before using the machine.

Please check every day that all belts, bearings and moving parts are in good condition because this could lead to something breaking and causing injury. Make sure the grinding plate is attached securely, using the appropriate allen key.

### USING THE MACHINE

**When the machine is not in use, it should always be left on the stand.** Some models have a lever next to the control box. Others have a foot pedals to engage the stand and keep the disc off the floor. Make sure that the emergency stop has been twisted all the way out. To start the machine press either the green button or the No. 1 button, depending on the machine. This process should always be done with the disc tilted back off the floor. Lower the machine down onto the floor keeping the disc moving into different areas to reduce swirl marks and avoid grooves forming. When the machine pauses, for example coming up to an obstacle, make sure the disc is lifted off the floor to avoid similar holes and swirl marks. To stop the machine, press the black button. We recommend that this machine has appropriate dust control fitted when in use.

### AFTER USING AND PRIOR TO RETURNING THE MACHINE

Please ensure that the machine is unplugged and kept in a safe place and is back on its stand.

An off-hire will never be arranged at the beginning of the hire period. Please call the office and arrange collection as soon as you know when the machine/machines will no longer be required.

Please make sure the machine is returned in a fit and clean state to avoid charges.

If multiple machines are being collected, please have them placed neatly together, ready to collect because time may be charged if we have to search or wait for equipment. Items not available for collection will remain on hire and additional collection charges will apply. If the machine is to be collected by a carrier, please ensure it's strapped securely to the pallet using the straps that it arrived with and is left somewhere obvious and preferably arrange for someone to be responsible for supervising the collection.

All information above is provided for guideline purposes only. For more accurate and reliable information please refer to the manufacturer.

Multi-Hire Power Tools

Warrington

[www.multi-hire.co.uk](http://www.multi-hire.co.uk)

01925 653633