Polisher/scrubber

Weight(kg)	Height(mm)	Width(mm)	Length(m)	Hand arm vibration	Noise(db)	
40	1200	430	542	2.5-5.6	58	
				D To be use trained. authoris person only	and sed nel	

EACH TIME BEFORE USING MACHINE

This machine should only ever be used by a trained and/or competent person.

Check that the machine has in no way been damaged in transit or whilst on site. If you have any questions or doubts, please contact the office prior to use. Please report any damage to the office prior to use.

Please check that all safety mechanisms are intact and working correctly

Please make sure that the floor you're about to prep is clear and has no foreign objects that could cause damage to the machine or operator. This must be completed every time before you start to use the machine.

Please check every new day that all bearings and moving parts are all in good condition because this could lead to breakage and even injury.

USING THE MACHINE

Firstly, connect the drive plate (head) to the machine by placing it into the grooves and twisting it until it locks on. Then lower the machine onto the floor so that the disc lines up to the head.

To lower and raise the handle, use the large lever and put pressure on the handle. To start the machine press in both trigger switches. Use the handle to control the direction of the machine. A little movement up and down will cause the machine to move left and right.

AFTER USAGE AND RETURNING THE MACHINE

Please ensure that the machine is unplugged and kept in a safe place.

An off-hire will never be arranged at the beginning of the hire period. Please call the office and arrange collection as soon as you know when the machine/machines will not be in use.

Please make sure the machine is returned is a fit, clean state as charges may apply if not.

If multiple machines are being collected, please have them placed neatly together, ready to collect because time may be charged if we have to search or wait for equipment. Items not available for collection will remain on hire and additional collection charges will apply. If the machine is to be collected by a carrier, please ensure it's strapped securely to the pallet using the straps that it arrived with and is left somewhere obvious and preferably arrange for someone to be responsible for supervising the collection.

All information above is provided for guild line purposes only. For more accurate and reliable

Information please refer to the manufacturer.

Multi-hire power tools

Warrington

www.multi-hire.co.uk

01925653633