## Electric floor saw

Weight(kg)	Height(mm)	Width(mm)	Length(m)	Hand arm	Noise(db)
				vibration	
9				4.5m/s	90













## **EACH TIME BEFORE USING MACHINE**

This machine should only ever be used by a trained and competent person.

Upon acceptance, please check the machine has in no way been damaged intransit and works, and each time prior to use. If you have any questions or doubts, please contact us, also in the event of breakdown or damage.

Please check that all safety mechanisms and switches are intact and working correctly.

Please make sure that the floor you're about to prep is clear of all foreign objects that could cause damage to the machine or operator. This must be completed every time before using the machine.

Please check every day that all belts, bearings and moving parts are in good condition because this could lead to something breaking and causing injury.

## **USING THE MACHINE**

Make sure the blade is on properly and that the blade nut is tight. Turn on the switch and the blade should start to spin. It is important to make sure that no parts of your person or colleagues go near the blade whilst it is rotating. Turn the machine on and slowly lower the blade into the concrete to the desired depth. To turn the machine off flick the switch the opposite way. We recommend that you always use dust extraction with this machine.

## AFTER USING AND PRIOR TO RETURNING THE MACHINE

Please ensure that the machine is unplugged and kept in a safe place.

An off-hire will never be arranged at the beginning of the hire period. Please call the office and arrange collection as soon as you know when the machine/machines will no longer be required.

Please make sure the machine is returned in a fit and clean state to avoid charges.

If multiple machines are being collected, please have them placed neatly together, ready to collect because time may be charged if we have to search or wait for equipment. Items not available for collection will remain on hire and additional collection charges will apply. If the machine is to be collected by a carrier, please ensure it's strapped securely to the pallet using the straps that it arrived with and is left somewhere obvious and preferably arrange for someone to be responsible for supervising the collection.

All information above is provided for guideline purposes only. For more accurate and reliable information please refer to the manufacturer.

Multi-Hire Power Tools
Warrington

www.multi-hire.co.uk

01925 653633