

## **MEDIUM BREAKER**

Weight(kg)	Height(cm)	Width(cm)	Length(cm)	Hand arm vibration	Noise(db)
11.5	10cm	25cm	71cm	8.5m2	105



### **EACH TIME BEFORE USING MACHINE**

This machine should only ever be used by a trained and/or competent person.

Check that the machine has in no way been damaged in transit or whilst on site. If you have any questions or doubts, please contact the office prior to use. Please report any damage to the office prior to use.

Please check that all safety mechanisms are intact and working correctly

Please make sure that the floor you're about to prep is clear and has no foreign objects that could cause damage to the machine or operator. This must be completed every time before you start to use the machine.

please check every new day that all belts, bearings and moving parts are all in good condition as this could lead to something breaking and causing an injury.

### **USING THE MACHINE**

make sure the machine is unplugged, the kango 900 place in the accessory and twist so that it is locked in. Do the reverse to take out. The hilti 905/1000 insert to lock in to remove pull back the collar at the end of the chuck and pull the accessory

Plug the machine in and return upright. Use the switch on the handle or back of the machine to operate the machine.

Be careful with the surrounding area as concrete can chip and fly away.

To stop the machine let go of the trigger switch or switch off at the back.

When changing the accessories please revert back to first point.

### **AFTER USAGE AND RETURNING THE MACHINE**

Please ensure that the machine is unplugged and kept in a safe place.

An off-hire will never be arranged at the beginning of the hire period. Please call the office and arrange collection as soon as you know when the machine/machines will not be in use.

Please make sure the machine is returned in a fit, clean state as charges may apply if not.

If multiple machines are being collected, please have them neatly together ready to collect as time may be charged if we have to search or wait for equipment.

All information above is provided for guideline purposes only. For more accurate and reliable

Information please refer to the manufacturer.